



Tel: +31 (0)76 596 9250
Email: pigpost@newpig.com

PRODUCT DATA SHEET

Item Number	: ORLS300
Item Name	: PIG® Essentials Oil-Only Mat Rolls
Contents/Package	: 2 rolls/package
Colour	: White
Dimensions	: 91.4 m x 38 cm
Composition	: 100% Polypropylene
Absorbency	: 257 L/Package
Weight	: 13.6 Kg

Description

- Loose stacked-weave design increases surface area on spill; mat starts wicking on contact to save time in critical situations
- Works equally well on land or water; floats when fully saturated
- MeltBlown Mat provides quick, efficient cleanup to help protect the environment from contamination
- MeltBlown polypropylene fibres are naturally hydrophobic and repel water (and float) while only absorbing oils and other hydrocarbons
- Large-diameter MeltBlown polypropylene fibres are randomly assembled to create a lofty Mat that absorbs high volumes of liquid fast