



Tel: +31 (0)76 596 9250
Email: pigpost@newpig.com

PRODUCT DATA SHEET

Item Number	: MPL200
Item Name	: PIG® Essentials Universal Mat Pads
Liquids Absorbed	: Oil, Coolants, Solvents & Water
Contents/Package	: 100 pads/package
Colour	: Grey
Dimensions	: 46 cm x 38 cm
Composition	: 100% Polypropylene
Absorbency	: 83,3 L/Package
Weight	: 4.1 Kg

Description

- Sturdy and soft but has a higher loft than standard mats for greater economy without compromising sorbency
- Between SingleWeight and MediumWeight but able to take in 30 times its own weight in liquids
- A random assembly of large-diameter MeltBlown poly fibers creates a lofty Pad that absorbs high volumes of liquid fast
- Great for catching overspray or soaking up spills
- Ultrasonic bond points fuse layers of fibers together — Mat keeps its shape even when completely saturated
- Perforated every 19 cm lengthwise