



Tel: +31 (0)76 596 9250
Email: pigpost@newpig.com

PRODUCT DATA SHEET

Item Number	: SKM401
Item Name	: PIG® Monitoring Well Skimming Sock
Contents/Package	: 30 socks/box
Colour	: White
Dimensions	: 3,8 cm Dia x 46 cm
Composition	: Skin - Polypropylene, Filler - Polypropylene
Absorbency	: 15 L/Box
Weight	: 2.7 Kg

Description

- Simply lower this floating sump skimmer into a monitoring well to absorb oils without taking in any water
- Spunbond polypropylene skin is UV resistant up to 12 months; meets ANSI and MIL spec standards for static decay
- Polypropylene loop can be attached to rope (not included) for easy deployment and retrieval
- Bright white colour makes absorbed oil easier to see; clearly shows saturation level
- Can be incinerated after use to reduce waste or for fuels blending

Recycled Content	: 98% Pre-Consumer Recycled Polypropylene Filler
-------------------------	--