



**Tel:** +31 (0)76 596 9250  
**Email:** pigpost@newpig.com

# PRODUCT DATA SHEET

<b>Item Number</b>	: MAT280
<b>Item Name</b>	: PIG® Traffic MAT® Rug
<b>Contents/Package</b>	: 1 roll/bag
<b>Colour</b>	: Black
<b>Dimensions</b>	: 91cm W x 46m L
<b>Composition</b>	: Polypropylene
<b>Absorbency</b>	: 74 L/Bag
<b>Weight</b>	: 11.8 Kg

## Description

- 100% polypropylene material is heat fused and needle punched for incredible durability for walk-on and wheeled traffic
- Our most durable mat won't rip, shred or fray, even under heavy forklift traffic!
- Dark grey colour hides grime, so mat stays on the job longer
- Rolls are ideal for walkways and large areas to soak up leaks and overspray
- Can be incinerated after use to reduce waste or for fuels blending