



Tel: +31 (0)76 596 9250
Email: pigpost@newpig.com

PRODUCT DATA SHEET

Item Number	: TLS190
Item Name	: PIG® Low-Profile Leak Diverter
Contents/Package	: 1 each
Colour	: Yellow
Dimensions	: ext. dia. 29cm x 23cm H
Composition	: PVC, Polyester

Description

- Low-profile design and compact size let you target a specific leak in tight spaces
- Nonpermeable material is vinyl-coated for strength and durability; resists punctures and mildew for long life
- UV resistant up to 12 months for long-term outdoor use without degradation
- Built-in grommets and rubber straps (sold separately) make it easy to hang from an overhead pipe
- Accepts a standard 3/4" hose connection to safely channel liquid to floor drain or collection container (hose sold separately)

Warnings & Restrictions	: Not suitable for temperatures over 77°C.
------------------------------------	--